



HELPFUL HINT:
 WEDGE BEHIND BEVELED BLOCK CAN BE A
 GOOD PLACE TO RUN ELECTRICAL WIRES
 AFTER ROOF PANEL SCREWS ARE IN PLACE.

BEVELED BLOCK WALL TO ROOF

DETAIL NUMBER:

1301

SCALE : NTS

Updated: 3/17/2017

LAMIT INDUSTRIES

STRUCTURAL INSULATED PANELS
 FOR THE BUILDING INDUSTRY