

TRUFAST SCREWS @ 12" O.C. W/ MINIMUM 1" PENETRATION INTO TOP PLATE MATERIAL (U.N.O.)

#8x1 1/2" SCREWS OR 8d NAILS @ 12" O.C. STAGGERED IN 5/8" PLYWOOD SPLINE BY OTHERS

7/16" OSB ROOF SHEATHING

2'-0"

#8x1 1/2" SCREWS @ 8" O.C. OR 8d NAILS @ 6" O.C. ALONG RAFTER TAIL (U.N.O.)

LAMIT ROOF PANEL

4"

2x6 RAFTER TAIL CUT TO SPECIFIED OVERHANG LENGTH

2x RAFTER TAIL SUPPORT CUT TO FIT SPACE BETWEEN RAFTER TAIL AND BOTTOM SKIN OF ROOF PANEL ATTACHED W/ #9x3" SCREWS OR 16d NAILS (2'-0" MAXIMUM OVERHANG)

USE 2 PART EXPANDABLE FOAM TO SEAL GAPS AROUND TAIL POCKET MATERIAL AFTER INSTALLATION

FACTORY REMOVED EPS FOAM VOID TO ALLOW INSERTION OF RAFTER TAIL

SIP TAPE ON WARM SIDE OF PANEL

2x TOP PLATE

LAMIT WALL PANEL

NOTE:  
2x4 RAFTER TAILS ARE USED W/ 8 1/4" ROOF PANELS

**NOTE: MAXIMUM 42# LIVE LOAD**

## RAFTER TAIL RAKE

DETAIL NUMBER:

**1415**

**SCALE : NTS**

**Updated: 3/17/2017**

**LAMIT INDUSTRIES**

STRUCTURAL INSULATED PANELS  
FOR THE BUILDING INDUSTRY